











- (D)** Montageanleitung
- (NL)** Handleiding voor de montage
- (TR)** Montaj talimatı
- (FR)** Instructions de montage
- (CZ)** Montážní návod
- (HU)** Összeszerelési útmutató
- (GB)** Assembly instructions
- (PL)** Instrukcja montażu
- (RU)** Инструкция по монтажу
- (IT)** Istruzioni di montaggio
- (RO)** Instructiuni de asamblare
- (SK)** Montážny návod








A	B	C (mm)		D
1	M130-001	396	1856	2/2
2	M130-002	1856	195	2/2
3	M130-101	1949	354	1/2
4	M130-102	1949	354	1/2
5	M130-201	720	354	1/2
6	M130-202	720	354	1/2
7	M130-301	687	334	1/2
8	M130-302	686	334	1/2
9	M130-571	1862	60	2/2
10	M130-572	721	60	2/2
11	M130-9901	1958	697	1/2




90 min




1 












6

5








8 



9



Pflegehinweis!

Bitte nur mit einem Staubtuch (kein Microfasertuch) oder einem feuchten Lappen reinigen. KEINE scheuernden Putzmittel verwenden!

Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko wilgotną szmatką do kurzu. Nie używać żadnych środków szorstkich!

